



Strain relief accessories




The DH spacer sleeve is required for stacking the ZL strain relief plate. This allows for cables to be stacked, thereby saving space.

The ELB insert bushing can be laid into the strain relief plate type ZL. It prevents cold flow of the plastic at the fixing point during heavy strain or permanent movement.







DH...

ELB...

Two-tier assembly

| Туре | Order no. | A | В | C | G | Н | Pack |
|-------------------|-----------|------|------|-----|------|------|------|
| | | mm | mm | mm | mm | mm | qty |
| | | | | | | | |
| For ZL 04 and ZL | _ 05 | | | | | | |
| DH 30/8 | 87701054 | 30.0 | 8.5 | 5.2 | 26.0 | 44.0 | 1 |
| | | | | | | | |
| For ZL39-180/8 | | | | | | | |
| ELB / 6 | 87701050 | 6.5 | 12.0 | 6.2 | - | - | 1 |
| ELB/8 * | 87701060 | 6.5 | 13.4 | 8.2 | - | - | 1 |
| DH 32/6 | 87701052 | 32.0 | 12.0 | 6.3 | 28.0 | 46.0 | 1 |
| DH 32/8 * | 87701062 | 32.0 | 13.0 | 8.3 | 28.0 | 46.0 | 1 |
| | | | | | | | |
| * for ZL 180/8 or | nly | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |